

Nissin Model (Canon Version)	Di866	Di866 Mark II	Di622	Di622 Mark II	Di466	Di28
<b>Canon D-SLR Cameras</b>						
EOS 1D / 1Ds	○	○	○	○	○	○
EOS 1D Mark II (N)	●	●	○	●	●	○
EOS 1D Mark III	●	●	○	●	●	○
EOS 1D Mark IV	●	●	○	●	●	○
EOS 5D	●	●	●	●	●	●
EOS 5D Mark II	● 4	●	○	●	○	●
EOS 7D	● 4	●	●	●	●	●
EOS 10D	●	●	●	●	●	●
EOS 20D	●	●	●	●	●	●
EOS 30D	●	●	●	●	●	●
EOS 40D	●	●	●	●	●	●
EOS 50D	●	●	●	●	●	●
EOS 60D	●	●	● 4	●	○	●
EOS 300D (Rebel X)	●	●	●	●	●	●
EOS 350D (Rebel XT)	●	●	●	●	●	●
EOS 400D (Rebel XTi)	●	●	●	●	●	●
EOS 450D (Rebel XSi)	●	●	●	●	●	●
EOS 500D (Rebel T1i)	●	●	●	●	●	●
EOS 550D (Rebel T2i)	●	●	●	●	●	●
EOS 600D (Rebel T3i)	●	●	○	●	●	○
EOS 1000D (Rebel XS)	●	●	●	●	●	●
EOS 1100D (Rebel T)	●	●	○	●	●	○
<b>Compact Cameras</b>						
PowerShot G7 / G9 / G10	● 1	○	●	●	●	●
PowerShot G11	● 1	○	○	○	○	○
PowerShot S5 IS	● 1	○	●	●	●	●
PowerShot SX1 IS	● 1	○	○	○	○	○
PowerShot SX10 IS	● 1	○	●	●	●	●
PowerShot SX20 IS	● 1	○	○	○	○	○

Remarks:

- 1) Hi-Speed is not supported
- 2) Guide Number drops at focal lengths of 300mm (35mm format equivalent) or longer
- 3) FV Lock system does not work
- 4) Firmware update

Nissin Model (Nikon version)	Di866	Di866 Mark II	Di622	Di622 Mark II	Di466	Di28
<b>Nikon D-SLR Camera</b>						
D2Xs	●	●	○	●	●	●
D3 / D3X	●	●	●	●	●	●
D3s	●	●	○	●	○	○
D40 / D40X	●	●	●	●	●	●
D50	●	●	●	●	●	●
D60	●	●	●	●	●	●
D70 / D70s	●	●	●	●	●	●
D80	●	●	●	●	●	●
D90	●	●	●	●	●	●
D200	●	●	●	●	●	●
D300	●	●	●	●	●	●
D300s	●	●	●	●	●	●
D700	●	●	● 3	●	● 3	● 3
D3000	●	●	●	●	●	●
D3100	●	●	●	●	●	●
D5000	●	●	●	●	●	●
D5100	●	●	○	●	○	●
D7000	● 4	●	○	●	○	○
<b>Compact Cameras</b>						
Coolpix P5000	○	○	○	○	●	●
Coolpix P5100	○	○	○	○	●	●
Coolpix P6000	○	○	○	○	○	○
<b>Fujifilm D-SLR Cameras</b>						
Finepix S3 Pro	○	○	○	○	○	○
Finepix S5 Pro	●	○	● 3	○	●	●
Remarks:						
1) Hi-Speed is not supported						
2) Guide Number drops at focal lengths of 300mm (35mm format equivalent) or longer						
3) FV Lock system does not work						
4) Firmware update						

Nissin Model (Sony Version)	Di866 Mark II	Di622 Mark II
-----------------------------	---------------	---------------

Sony D-SLR Cameras		
--------------------	--	--

Alpha 100	●	●
Alpha 200	●	●
Alpha 230	●	●
Alpha 290	●	●
Alpha 300	●	●
Alpha 330	●	●
Alpha 350	●	●
Alpha 380	●	●
Alpha 500	●	●
Alpha 550	●	●
Alpha 580	●	●
Alpha 700	●	●
Alpha 850	●	●
Alpha 900	●	●
Alpha SLT A33	●	●
Alpha SLT A55V	●	●

